

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA																																																																								
<div><div><div>Ladder symbol</div><div><div>Execution control — EN —</div><div><div>141.MPARA</div><div><div>Ps : <div></div></div><div>SR : <div></div></div></div><div>ERR —</div></div></div><div><div>Ps: The set number of Pulse Output (0~3).</div><div>SR: Starting register for parameter table, it has totally 18 parameters which controlled by 24 registers.</div></div><table><tr><td>Range</td><td>HR</td><td>DR</td><td>ROR</td><td>K</td></tr><tr><td>Ope- rand</td><td>R0   R3839</td><td>D0   D3999</td><td>R5000   R8071</td><td></td></tr><tr><td>Ps</td><td></td><td></td><td></td><td>0~3</td></tr><tr><td>SR</td><td>○</td><td>○</td><td>○</td><td></td></tr></table></div></div>			Range	HR	DR	ROR	K	Ope- rand	R0   R3839	D0   D3999	R5000   R8071		Ps				0~3	SR	○	○	○																																																					
Range	HR	DR	ROR	K																																																																						
Ope- rand	R0   R3839	D0   D3999	R5000   R8071																																																																							
Ps				0~3																																																																						
SR	○	○	○																																																																							
<div>Instruction explanation</div> <div><div>1. This instruction is not necessary if the system default for parameter value is matching what users need. However, if it needs to open the parameter value to do dynamic modification, this instruction is required.</div><div>2. This instruction incorporates with FUN140 or FUN147 for positioning control purpose, each axis can have one FUN141 instruction only.</div><div>3. Whether the execution control input “EN” = 0 or 1, anyway, this instruction will be performed.</div><div>4. When there is error in parameter value, the output indication “ERR” will be ON, and the error code is appeared in the error code register.</div></div> <div>Explanation for the parameter table:</div> <div>SR =Starting register of parameter table, suppose it is R2000.</div> <table><tr><td>R2000 (SR+0)</td><td>0~2</td><td>Parameter 0</td><td>System default =1</td></tr><tr><td>R2001 (SR+1)</td><td>1~65535 Ps/Rev</td><td>Parameter 1</td><td>System default =2000</td></tr><tr><td>DR2002 (SR+2)</td><td>1~999999 μM/Rev 1~999999 mDeg/Rev 1~99999930.1 mInch/Rev</td><td>Parameter 2</td><td>System default =2000</td></tr><tr><td>R2004 (SR+4)</td><td>0~3</td><td>Parameter 3</td><td>System default =2</td></tr><tr><td>DR2005 (SR+5)</td><td>1~921600 Ps/Sec 1~153000</td><td>Parameter 4</td><td>System default =460000</td></tr><tr><td>DR2007 (SR+7)</td><td>0~921600 Ps/Sec 1~153000</td><td>Parameter 5</td><td>System default =141</td></tr><tr><td>R2009 (SR+9)</td><td>1~65535 Ps/Sec</td><td>Parameter 6</td><td>System default =1000</td></tr><tr><td>R2010 (SR+10)</td><td>0~32767</td><td>Parameter 7</td><td>System default =0</td></tr><tr><td>R2011 (SR+11)</td><td>0~30000</td><td>Parameter 8</td><td>System default =5000</td></tr><tr><td>R2012 (SR+12)</td><td>0~10~1</td><td>Parameter 9</td><td>System default =0100H</td></tr><tr><td>R2013 (SR+13)</td><td>-32768~32767</td><td>Parameter 10</td><td>System default =0</td></tr><tr><td>R2014 (SR+14)</td><td>-32768~32767</td><td>Parameter 11</td><td>System default =0</td></tr><tr><td>R2015 (SR+15)</td><td>0~30000</td><td>Parameter 12</td><td>System default =0</td></tr><tr><td>R2016 (SR+16)</td><td>0~30000</td><td>Parameter 13</td><td>System default =500</td></tr><tr><td>DR2017 (SR+17)</td><td>0~1999999</td><td>Parameter 14</td><td>System default =0</td></tr><tr><td>DR2019 (SR+19)</td><td>00H~FFH00H~FFH00H~FFH00H~FFH</td><td>Parameter 15</td><td>System default =FFFFFFFFH</td></tr><tr><td>DR2021 (SR+21)</td><td>-999999~999999</td><td>Parameter 16</td><td>System default =0</td></tr><tr><td>R2023 (SR+23)</td><td>0~255</td><td>Parameter 17</td><td>System default =1</td></tr></table>			R2000 (SR+0)	0~2	Parameter 0	System default =1	R2001 (SR+1)	1~65535 Ps/Rev	Parameter 1	System default =2000	DR2002 (SR+2)	1~999999 μM/Rev 1~999999 mDeg/Rev 1~99999930.1 mInch/Rev	Parameter 2	System default =2000	R2004 (SR+4)	0~3	Parameter 3	System default =2	DR2005 (SR+5)	1~921600 Ps/Sec 1~153000	Parameter 4	System default =460000	DR2007 (SR+7)	0~921600 Ps/Sec 1~153000	Parameter 5	System default =141	R2009 (SR+9)	1~65535 Ps/Sec	Parameter 6	System default =1000	R2010 (SR+10)	0~32767	Parameter 7	System default =0	R2011 (SR+11)	0~30000	Parameter 8	System default =5000	R2012 (SR+12)	0~10~1	Parameter 9	System default =0100H	R2013 (SR+13)	-32768~32767	Parameter 10	System default =0	R2014 (SR+14)	-32768~32767	Parameter 11	System default =0	R2015 (SR+15)	0~30000	Parameter 12	System default =0	R2016 (SR+16)	0~30000	Parameter 13	System default =500	DR2017 (SR+17)	0~1999999	Parameter 14	System default =0	DR2019 (SR+19)	00H~FFH00H~FFH00H~FFH00H~FFH	Parameter 15	System default =FFFFFFFFH	DR2021 (SR+21)	-999999~999999	Parameter 16	System default =0	R2023 (SR+23)	0~255	Parameter 17	System default =1
R2000 (SR+0)	0~2	Parameter 0	System default =1																																																																							
R2001 (SR+1)	1~65535 Ps/Rev	Parameter 1	System default =2000																																																																							
DR2002 (SR+2)	1~999999 μM/Rev 1~999999 mDeg/Rev 1~99999930.1 mInch/Rev	Parameter 2	System default =2000																																																																							
R2004 (SR+4)	0~3	Parameter 3	System default =2																																																																							
DR2005 (SR+5)	1~921600 Ps/Sec 1~153000	Parameter 4	System default =460000																																																																							
DR2007 (SR+7)	0~921600 Ps/Sec 1~153000	Parameter 5	System default =141																																																																							
R2009 (SR+9)	1~65535 Ps/Sec	Parameter 6	System default =1000																																																																							
R2010 (SR+10)	0~32767	Parameter 7	System default =0																																																																							
R2011 (SR+11)	0~30000	Parameter 8	System default =5000																																																																							
R2012 (SR+12)	0~10~1	Parameter 9	System default =0100H																																																																							
R2013 (SR+13)	-32768~32767	Parameter 10	System default =0																																																																							
R2014 (SR+14)	-32768~32767	Parameter 11	System default =0																																																																							
R2015 (SR+15)	0~30000	Parameter 12	System default =0																																																																							
R2016 (SR+16)	0~30000	Parameter 13	System default =500																																																																							
DR2017 (SR+17)	0~1999999	Parameter 14	System default =0																																																																							
DR2019 (SR+19)	00H~FFH00H~FFH00H~FFH00H~FFH	Parameter 15	System default =FFFFFFFFH																																																																							
DR2021 (SR+21)	-999999~999999	Parameter 16	System default =0																																																																							
R2023 (SR+23)	0~255	Parameter 17	System default =1																																																																							


FUN 141  
MPARA

## Instruction of Parameter Setting for Positioning Program

FUN 141  
MPARA

## Editing Servo Parameter Table with WinProladder

Click the "Servo Parameter Table" Item which in project windows :



**Table Edit**

Table Properties

Table Type: Servo Parameter Table

Table Name: Servo Parameter Table

Table starting address: R5000

Table Capacity: ☒ Dynamic Allocation ☐ Fixed Length 24 (Unit:WORD)

☐ Load Table From PLC

Description

Servo Parameter Table Example!!!

OK Cancel

- Table Type : It will be fixed to " Servo Parameter Table ".
- Table Name : For modify or debug, you can give a convenient name.
- Table Starting address : Enter the address which Starting register of Servo Parameter Table.

FUN 141  
MPARA

## Instruction of Parameter Setting for Positioning Program

FUN 141  
MPARA

Servo Parameter Table - [Servo\_Table]

Calculator(C) Setup(S)

0.Unit :	1:Pulse	10.+ Movement Compensation :	0	Ps
1.Pulse/Rev.(16Bit):	2000	11.- Movement Compensation :	0	Ps
2.Distance/Rev. :	2000	12.Dec. Time :	0	mS
3.Min. Unit :	2	13.Interpolation Time Constant:	500	mS
4.Max. Speed :	460000	14.Pulse/Rev.(32Bit):	0	
5.Start/End Speed :	141	15_0.DOG Input:	Normal Oper	15 (X15)
6.Creep Speed:	1000	15_1.Stroke Input:	Normal Close	14 (X14)
7.Backlash Compensation :	0	15_2.PG0 Input:	Not Used	
8.Acc./Dec. Time :	5000	15_3.CLR Output:	Not Used	
9_0.Direction Control :	0:Up	16.Machine Zero Point:	0	Ps
9_1.Zero Return Direction:	1:Down(Left)	17.PG0 Count:	8	

Allow: 3072 words(Auto)    Used: 24 words    Position: R5000-R5023

Reset To Default    OK    Cancel

Explanation for the parameter:

- Parameter 0: The setting of unit, its default is 1.

- When the setting value is 0, the moving stroke and speed setting in the positioning program will all be assigned with the unit of mm, Deg, Inch, so called machine unit.
- When the setting value is 1, the moving stroke and speed setting in the positioning program will all be assigned with the unit of Pulse, so called motor unit.
- When the setting value is 2, the moving stroke setting in the positioning program will all be assigned with the unit of mm, Deg, Inch, and the speed setting will all be assigned with the unit of Pulse/Sec, which is called as compound unit.

Parameter 0, unit setting	"0" machine unit	"1" motor unit	"2" compound unit
Parameter 1, 2	Must be set	No need to set	Must be set
Parameter 3, 7, 10, 11	mm · Deg · Inch	Ps	mm · Deg · Inch
Parameter 4,5,6,15,16	Cm/Min · Deg/Min · Inch/Min	Ps/Sec	Ps/Sec

- Parameter 1: Pulse count/1-revolution, its default is 2000, i.e. 2000 Ps/Rev.

- The pulse counts needed to turn the motor for one revolution  
A= 1~65535 (for value greater than 32767, it is set with unsigned decimal) Ps/Rev
- When Parameter 14 = 0, Parameter 1 is the setting for Pulse /Rev
- When Parameter 14 ≠ 0, Parameter 14 is the setting for Pulse/Rev

- Parameter 2: Movement/1 revolution, its default is 2000, i.e. 2000 Ps/Rev.

- The movement while motor turning for one revolution.  
B=1~999999 μM/Rev  
1~999999 mDeg/Rev  
1~999999x0.1 mInch/Rev

FUN 141  
MPARA

## Instruction of Parameter Setting for Positioning Program

FUN 141  
MPARA

- Parameter 3: The resolution of moving stroke setting, its default is 2.

Parameter 0 Parameter 3	Set value=0, machine unit; Set value=2, compound unit;			Set value=1 motor unit (Ps)
	mm	Deg	Inch	
Set value =0	×1	×1	×0.1	×1000
Set value =1	×0.1	×0.1	×0.01	×100
Set value =2	×0.01	×0.01	×0.001	×10
Set value =3	×0.001	×0.001	×0.0001	×1

- Parameter 4: The limited speed setting, its default is 460000, i.e. 460000 Ps/Sec.

- Motor and compound unit: 1~921600 Ps/Sec.

- Machine unit: 1~153000 (cm/Min, ×10 Deg/Min, Inch/Min).

However, the limited frequency can't be greater than 921600 Ps/Sec.

$$f\_max = (V\_max \times 1000 \times A) / (6 \times B) \leq 921600 \text{ Ps/Sec}$$

$$f\_min \geq 1 \text{ Ps/Sec}$$

Note: A = Parameter 1, B =Parameter 2.

- Parameter 5: Initiate/Stop speed, the default = 141.

- Motor and compound unit: 1~921600 Ps/Sec.

- Machine unit: 1~15300 (cm/Min, ×10 Deg/Min, Inch/Min).

However, the limited frequency can't be greater than 921600 Ps/Sec.

- Parameter 6: Creep speed for machine zero return; the default is 1000.

Motor and compound unit : 1~65535 Ps/Sec

Machine unit : 1~15300 (Cm/Min, ×10 Deg/Min, Inch/Min)

- Parameter 7: Backlash compensation, the default =0. (Not used in linear interpolation instruction)

- Setting range: 0~32767 Ps.

- While backward traveling, the traveling distance will be added with this value automatically.

- Parameter 8: Acceleration/Deceleration time setting, (Not used in linear interpolation instruction)  
the default = 5000, and the unit is mS.

- Setting range: 0~30000 mS.

- The setting value represents the time required to accelerate from idle state up to limited speed state or decelerate from the limited speed state down to the idle state.

- The acceleration/deceleration is constant slope depending on Parameter 4 / Parameter 8

- When Parameter 12 = 0, Parameter 8 is the deceleration time


- There will have the auto deceleration function for short stroke movement.

- Parameter 9: Rotation and zero return direction; the default is 0100H (Not used in linear interpolation mode)

	b15	b8 b7	b0
SR+12	Para 9-1	Para 9-0	

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA												
<ul style="list-style-type: none"><li>• Parameter 9-0 : Rotation direction setting; the default is 0 Setting value=0, the present value increases while in forward pulse output; the present value decreases while in backward pulse output Setting value=1, the present value decreases while in forward pulse output; the present value increases while in backward pulse output</li><li>• Parameter 9-1 : Zero return direction setting; the default is 1 Setting value=0, direction in which the present value increases. Setting value=1, direction in which the present value decreases.</li><li>● Parameter 10: Forward movement compensation, the default = 0. (Not used in linear interpolation instruction)<ul style="list-style-type: none"><li>• Setting range: -32768~32767 Ps.</li><li>• When it is in forward pulse output, it will automatically add with this value as the moving distance.</li></ul></li><li>● Parameter 11: Backward movement compensation, the default =0. (Not used in linear interpolation instruction)<ul style="list-style-type: none"><li>• Setting range: -32768~32767 Ps.</li><li>• When it is in backward pulse output, it will automatically add with this value as the moving distance.</li></ul></li><li>● Parameter 12: Deceleration time setting, and the unit is mS. (default =0) ( Not used in linear interpolation mode)<ul style="list-style-type: none"><li>• Setting range: 0~30000 mS.</li><li>• When Parameter 12 = 0, Parameter 8 is the deceleration time</li><li>• When Parameter 12 ≠ 0, Parameter 12 is the deceleration time</li></ul></li><li>● Parameter 13: Interpolation time constant; the default is 500.<ul style="list-style-type: none"><li>• Setting range : 0~30000 mS</li><li>• Set the time required to achieve the speed specified by the program. (The initiate speed is always regarded as “0”.)</li><li>• This parameter is valid while interpolation control</li></ul></li><li>● Parameter 14: Pulse count/1-revolution, the default = 0.<ul style="list-style-type: none"><li>• The pulse counts needed to turn the motor for one revolution</li><li>• Setting range is 0~1999999</li><li>• When Parameter 14 = 0, Parameter 1 is the setting for Pulse /Rev</li><li>• When Parameter 14 ≠ 0, Parameter 14 is the setting for Pulse/Rev</li></ul></li><li>● Parameter 15: I/O control interface for DRVZ; the default is FFFFFFFFH</li></ul> <table><tr><td></td><td>b15</td><td>b8 b7</td><td>b0</td></tr><tr><td>SR+19</td><td colspan="2">Para 15-1</td><td>Para 15-0</td></tr><tr><td>SR+20</td><td colspan="2">Para 15-3</td><td>Para 15-2</td></tr></table> <ul style="list-style-type: none"><li>• Parameter 15-0 : Setting of DOG input (SR+19), it must be the input of the main unit b6~b0 : Reference number of DOG input (0~15, it means X0~X15) b7 = 0 : Contact A or Normal Open = 1 : Contact B or Normal Close b7~b0=FFH, Without DOG input</li></ul>				b15	b8 b7	b0	SR+19	Para 15-1		Para 15-0	SR+20	Para 15-3		Para 15-2
	b15	b8 b7	b0											
SR+19	Para 15-1		Para 15-0											
SR+20	Para 15-3		Para 15-2											

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA
<div><ul style="list-style-type: none"><li>• Parameter 15-1 : Setting of stroke limit input (SR+19) b14~b8 : Reference number of limit input (0~125, it means X0~X125) b15 = 0 : Contact A or Normal Open = 1 : Contact B or Normal Close b15~b8=FFH, Without limit input</li><li>• Parameter 15-2 : Setting of PG0 signal input (SR+20), it must be the input of the main unit b6~b0 : Reference number of PG0 input ( 0~15, it means X0~X15) b7 = 0 : Start counting at front end of sensing DOG input b7 = 1 : Start counting at rear end of sensing DOG input b7~b0 = FFH, Without PG0 input</li><li>• Parameter 15-3 : Setting of CLR signal output (SR+20), it must be the output of the main unit b15~b8 : Reference number of CLR output ( 0~23, it means Y0~Y23) b15~b8=FFH, Without CLR output</li></ul><div><ul style="list-style-type: none"><li>● Parameter 16: Machine zero point address; the default is 0 Setting range : -999999~999999 Ps</li><li>● Parameter 17: Number of zero point signals (Sensing of PG0 input); the default is 1. Setting range : 0~255 Count</li></ul></div></div>		
<div></div>		

FUN 141 MPARA	Instruction of Parameter Setting for Positioning Program	FUN 141 MPARA
<div data-bbox="263 385 1275 969"></div> <div data-bbox="194 1068 1415 1292"><ul style="list-style-type: none"><li>※ The parameter 13 of the axis with longest movement is used for acceleration and deceleration control for linear interpolation if each axis owns its own motion parameter table</li> <li>※ Using the same motion parameter table (through FUN141 and give the same starting address of SR operand for each axis) for the simultaneous linear interpolation axes, it is the best way for multi-axis linear interpolation motion control</li></ul></div>		